



IDEAS TO TAKE CARE OF YOUR CLOTHES

#YO ME QUEDO EN CASA


CEICID

TRICKS TO AVOID IRONING

#YO ME QUEDO EN CASA


CEICID

TRICKS TO AVOID IRONING



INTERIOR
GARMENTS



T-SHIRTS



POLO
SHIRTS




SWEATSHIRTS



EASY IRON
SHIRTS AND
BLOUSES



TROUSERS:
JEANS AND
CHINOS




LOWER SPIN SPEED

AT HIGHER SPIN SPEED CLOTHES WILL BECOME MORE WRINKLED

LOWER THE SPIN SPEED TO 800 RPM

SET THE SPIN SPEED WITH THE SYMBOL 



LAY THE CLOTHES OUT WHILE STILL WARM

WHILE THE DRY CLOTHES ARE WARM, THEY WRINKLE MORE EASILY

AS SOON AS YOU TAKE THE CLOTHES OUT OF THE DRYER, LAY THEM OUT ON A TABLE

 #YOUMEQUEDOENCASA


CEICID

TRICKS TO AVOID IRONING



INTERIOR
GARMENTS



T-SHIRTS




POLO
SHIRTS



SWEATSHIRTS



EASY IRON
SHIRTS AND
BLOUSES



TROUSERS:
JEANS AND
CHINOS

COTTON

DRY THE CLOTHES LEAVING A BIT OF RESIDUAL
DAMPNESS

FLATTEN THEM ON THE TABLE WITH YOUR HANDS TO
GET RID OF ANY OF THE CREASES

MIXED FABRICS

DRY AT 50°-60°C / COTTON PROGRAM, 5-10 MIN

DRY IN DRYER UNTIL STILL A BIT DAMP

FLATTEN THEM TO GET RID OF ANY OF THE CREASES

LEAVE THEM ON A HANGER UNTIL THEY DRY
COMPLETELY

#YOMEQUEDOENCASA



CEICID

BLACK SHIRTS

#YO ME QUEDO EN CASA



BLACK SHIRTS



WASHING


30°-40°C, USING SYNTHETIC CYCLE PROGRAM



DETERGENT

USE LAUNDRY DETERGENT FOR BLACK CLOTHES
IF YOU DON'T HAVE IT, YOU CAN USE LAUDRY
DETERGENT FOR COLOURED CLOTHES

DON'T USE SOFTNER



DRYING

DRY AT 50°-60°C / COTTON PROGRAM, 5-10 MIN

DRY IN DRYER UNTIL STILL A BIT DAMP AND THE
LEAVE TO DRY ON A HANGER

#YOUMEQUEDOENCASA


CEICID

BLACK SHIRTS



IRONING

IRONING CAUSES THE FABRIC TO BECOME GLOSSY
IRON WITH VAPOUR WITH LOW PRESSURE

COLLAR AND CUFFS

ONLY IRON INSIDE OUT OR DON'T IRON THEM

SLEEVES

IRON WITH LOWER PREASURE OR IRON INSIDE
OUT WITHOUT LEAVING A CREASE

REST OF THE SHIRT


IRON INSIDE OUT

SWEATERS

#YO ME QUEDO EN CASA



WASHING SWEATERS



WASHING

CASMERE AND WOOL

20°C, USING THE HAND-WASH CYCLE PROGRAM

OTHER MATERIALS

20°-30°C, USING DELICATE CYCLE PROGRAM

LOWER SPIN SPEED TO 500-800 RPM

SET THE SPIN SPEED WITH THE SYMBOL 



DETERGENT

USE LAUNDRY DETERGENT FOR DELICATE CLOTHES
DON'T USE SOFTNER



DRYING

NEVER USE THE TUMBLE DRYER
LAY FLAT ON TOP OF A TOWEL



IRONING

IF THE SWEATER HAS BEEN LAID OUT WELL,
THERE'S NO NEED TO IRON IT

 #YO ME QUEDO EN CASA



CEICID

SPORTSWEAR

#YO ME QUEDO EN CASA



SPORTSWEAR



WASHING

30°C, USING SYNTHETIC CYCLE PROGRAM
CAN BE MIXED WITH DIFFERENT COLOURS
COTTON ITEMS ARE WASHED TOGETHER



DETERGENT

USE LAUNDRY DETERGENT FOR COLOURED
CLOTHES

DON'T USE SOFTNER



DRYING

HANG ON HANGERS AND LEAVE TO DRY
NEVER USE THE TUMBLE DRYER



IRONING

SPORTS CLOTHES DON'T NEED TO BE IRONED
ONCE THEY ARE DRY, THEY CAN BE FOLDED

#YOUMEQUEDOENCASA


CEICID